

INFLATABLE INSTRUCTIONS

WARNING READ INSTRUCTIONS CAREFULLY BEFORE USE

EMX Alpha / Beta / Delta / Gamma / Omega Ranges

SETUP - INFLATION

Recommended procedure below. For safety reasons it is recommended that 2 persons set up any marquee. Ensure area is free from any sharp objects & overhead objects.



Remove Inflatable Marquee from Protective Cover.



Roll out the marquee.



Lay the Inflatable Marquee out flat.



Marquee Accessories*
Layout your Walls and Awnings and confirm positioning.



Attach the accessories using zips.



Each leg on the marquee has a valve. Select valve to attach pump, screw inflatation value closed and leave cap off.

On all other valves screw tight and fix cap.



Connect the pump to selected Inflation Valve and begin inflation.



During the inflation process raise legs into the center until all legs are upright.



Ensure all legs are lined up and roof is centered. Check frame is firm.



Fix Steel Pins and Guide Ropes or attach Sandbags.

IMPORTANT NOTES:

Check the wind and weather conditions before commencing construction.

Ensure you have the correct ground fixings for your application.

When the marquee is in use, do not leave your marquee unattended.



Over pressure relief valve system, **DO NOT TOUCH.**

BACK DOWN - DEFLATION

Recommended procedure below. For safety reasons it is recommended that 2 persons set up any marquee. Ensure area is free from any sharp objects & overhead objects.





Remove Steel Pins and Guide Ropes or detach Sandbags.



Ensure area is clear of persons. Ensure area is dry and clean. Unscrew all valves to deflate Marquee.



Remove all air from the tubes.



Fold Marquee up neatly laying the Roof and Legs on top of each other. Roll Marquee up.



Pack the dry and clean Inflatable Marquee into Protective Cover.

IMPORTANT NOTES:

Ensure Roof and Walls Fabrics are completely dry before packing down and fitting the Protective Covers.

During transport do not put heavy items on top if the Marquee.

ACCESSORIES

INCLUDED ITEMS:



Pins



Sandbags



Pump



Repair Kit

NOT INCLUDED



Generator



Extension Lead



Hammer / Mallet



